



ULV36

INSTALLATION INSTRUCTIONS

- 1 Remove wiring cover
- 2 Secure power supply to mounting surface




3 Instal romex connectors in 1/2 KOs where nessesary



Refer to ULV36 Wiring Options (next page) to configure setup for the appropriate application



5 Replace wiring cover




Customer Service | 800-789-3810 | service@kelvix.com




ULV36

WIRING OPTIONS


PRIMARY SIDE DIMMING (120V ONLY)




PRIMARY SIDE SWITCHING (120-277V)



SECONDARY SIDE DIMMING (0-10V)



SECONDARY SIDE DIMMING (DMX)



Customer Service | 800-789-3810 | service@kelvix.com